HOW TO ORDER

TT-LINE

TT-LINE Ordering Code

TT | 40 | 1 | LG | T | P | C | J0150

TEMP RANGE

Code	Range
J0150	0 to 150, J Type, Thermocouple
J0200	0 to 200, J Type, Thermocouple
J0600	0 to 600, J Type, Thermocouple
K0100	0 to 100, K Type, Thermocouple
K0150	0 to 150, K Type, Thermocouple
K0200	0 to 200, K Type, Thermocouple
K0300	0 to 300, K Type, Thermocouple
K0600	0 to 600, K Type, Thermocouple
K1000	0 to 1000, K Type, Thermocouple
K1200	0 to 1200, K Type, Thermocouple
P0050	0 to 50, PT100, RTD Input
P0100	0 to 100, PT100, RTD Input
P0200	0 to 200, PT100, RTD Input
P0300	0 to 300, PT100, RTD Input
P0400	0 to 400, PT100, RTD Input
P1050	-10 to 50, PT100, RTD Input
P5050	-50 to 50, PT100, RTD Input

UNIT

Code	Unit
C	°C
F	°F

TYPE

Code	Type
J	Type J
K	Type K
T	Type T
P	PT100

OUTPUT

Code	Output
T	Linear to Temp
M	Linear to mV
R	Not Applicable

CASE

Code	Case
LG	LG Head

OPTION

Code	Option
0	Thermocouple
1	RTD 3 Wire

ITEM

Code	Item
40	4 - 20mA

TYPE

Temperature Transmitter